



GOOSKY S2 直升机

DX9 SPEKTRUM 遥控器参数设置


1. 新建一个模型（保持初始化） Create a new model (keep initialization)




2. 类别设置成直升机 The category is set to Helicopter



3. 设置油门锁定（HOLD） Set throttle lock (HOLD)






4. 设置 CH5 为起落架模式，设置开关用于控制姿态模式/3D 手动模式切换
Set CH5 as landing gear mode, and set the switch to control attitude mode/3D manual mode switching



5. 设置油门曲线 NORMAL、IDLE 1\IDLE 2

Set throttle curve NORMAL, IDLE 1\IDLE 2



6. 设置螺距曲线 NORMAL、IDLE 1\IDLE 2

Set the pitch curve NORMAL, IDLE 1\IDLE 2

